*1007 Citton Service C	entre	Pt	y I	_tc						
Name: Citton Cars	Job card:	10075	D	ate: 0)4/11	/202	23 09	:15:	00	
CK/Reg No:	Advisor:	Karika	Wes	sels						
Vat Reg No:	Reg no:	JP08k	KKGP			,	Year:	20	019	
Address:	Vehicle:	BMW	M140	i 5DF	R (F2	0)				
	KMs:	80368		Colo	ur:					
Phone:	Vin no:	WBA1	S920	707E	1053	30				
Time vehicle expected: Old parts required: Yes / No	Eng no:	22675	687							
CUSTOMER'S INSTRUCTIONS/WORK REQUIRED:	Fuel tank:	Е	1/4	1/2		3/4	F			
MOTORPLAN										
Front	r.									
11 10 9 8 Dent Scra Rust Crac Chip	tched ed ked	3 4	5 6	7	8 9	10	11 1	2 13	3 14	15
Valuables left in vehicle:										
Radio: Yes No CD's: Yes No No. of	· · · · · · · · · · · · · · · · · · ·									
Spare Wheel: Yes No Tools: Yes No No. of)				
ERMS & CONDITIONS:) I accept the technical advice given to me by the Vendor relating to the service) I accept the Vendor's estimated costs to perform diagnostics, including disas) I accept the Vendor's estimate for costs of service and parts, on condition I re) No additional service may be performed or parts provided without my express	e and/or repair sembly of my p	roperty.		ccept.						

We accept card payments and we reserve the right to withhold vehicles until funds reflect in our bank account should you do an

Please remove all valuables from your vehicle. Vehicle only released upon payment. Storage costs of R285.00 per day will be charged for vehicles not collected within 5 (five) working days of completion. All vehicles and contents left in our custody are parked, stored and driven at vehicle owners risk. I accept the above conditions and authorise you to do the work listed above at my expense and to supply and replace such parts and materials

including oil and fuel which may be necessary to complete the work set out above. I agree to the scale of charges as derailed on the schedule

EFT payment.

CONDITIONS OF CONTRACT:

displayed in the workshop office for inspection.

Customer's or Authorised Representative's Signature:

Job Card 10075 Detailed Checklist

				Description			Description
920	4.	FUEL AIR			9. ELECTRICAL		
	10	DLING VALVE	/		INTERIOR FAN	/	
/	В	REATHER HOSE	/		BRAKELIGHT SWITCH	/	
NA	T	URBO	/		OIL SWITCH	/	
1	C	ARBURETTOR	NA			/	
/			117			1	
/			/			/,	
1			/			/	
1/			-/-			/,	
-/,	1.	OLL LINL				/	
1,	-	ICHITION CVOTEM			INSTRUM. CLUSTER	/	
-			210				
-,-			11/1/			ENSION	
			/			/	
			/				
	D	ISTRIBUTOR	NA		CV BOOT	/	
	IG	SNITION SWITCH	/		WHEEL BEARINGS	/	
/	G	LOW PLUGS	NIA		BEARING HUBS		
1					SHOCKS	/	
/	6.	ENGINE OUTER - OIL	LEAKS		SHOCK MOUNTINGS	/	
/	RI	EAR MAIN SEAL	/		STABILIZER ARM	/	
/	SI	UMP GASKET/PLUG	/		CONTROL ARM		15
1			/			7	
/			7			/	
/			,			-/-	
/			,			-	
1						-	
/			-,		WHEEL COVERS		
1					44 TRANSMISSIONS 8	OL LITOU	
			/,		cation in the contract of the	CLUTCH	
/			,			/	
/	PO	CV VALVE	/				
/							
/	7.	STEERING				aubl)CX
			/		AUTO TRANSMISSION		
	S	TEER. SYST. LEAKS	/		TRANSFER BOX		
	S	TEER. RACK	/		GEAR LINKAGES		
/	TI	E ROD ENDS	/		GEAR SELECTOR ✓		
1	DI	RAG LINK	/				
/	ST	TEER. RACK ENDS	/		12. EXHAUST		
/	1A	NTIROLL BAR	/				
1	PO	OWER STEER, PUMP	7				
/			1		13 CYLINDER HEAD		
/					O LINDLIN HEAD		
/	0	AIRCON					
-					14 ENGINE POTTON D	ADT	
1			/		14. ENGINE BOTTOM P	AK I	
1,			/				
/							
/,			/		15. DOOR, WINDOW, LO	OCK, MIR	ROR
/			/,				
	E>	KP. VALVE			1. DIAGNOSTIC TESTS		
/		Y			COMRESSION TEST		
/	9.	ELECTRICAL			CYL. LEAKAGE TEST		
/	ST	TARTER	1				A
/	AL	TERNATOR	/				
		MISTER	1				
			CARBURETTOR INJECTORS INJECTOR WASHER FUEL PUMP FUEL LINE 5. IGNITION SYSTEM HIT LEADS IGNITION COIL IGNITION MODULE DISTRIBUTOR IGNITION SWITCH GLOW PLUGS 6. ENGINE OUTER - OIL REAR MAIN SEAL SUMP GASKET/PLUG DIP STICK OIL FILLER CAP FAN BELT FAN BELT FAN BELT FAN BELT FAN BELT POWER STEER. BELT AIRCON BELT MULTI V BELT ENGINE MOUNTING PCV VALVE 7. STEERING POWER STEER RACK STEER. SYST. LEAKS STEER. SYST. LEAKS STEER. RACK TIE ROD ENDS DRAG LINK STEER. RACK ENDS ANTIROLL BAR POWER STEER. PUMP WHEEL ALIGN-BALAN 8. AIRCON AIRCON SERV HEATER HOSE AIRCON CONSUM. AIR CON. PIPE EVAPORATOR CONDENSOR EXP. VALVE	BREATHER HOSE TURBO CARBURETTOR INJECTORS INJECTOR WASHER FUEL PUMP FUEL LINE 5. IGNITION SYSTEM HIT LEADS IGNITION MODULE DISTRIBUTOR IGNITION SWITCH GLOW PLUGS 6. ENGINE OUTER - OIL LEAKS REAR MAIN SEAL SUMP GASKET/PLUG DIP STICK DIP STICK OIL FILLER CAP FAN BELT FAN BELT FAN BELT FAN BELT FAN BELT POWER STEER BELT AIRCON BELT MULTI V BELT POWER STEER RACK STEER. RACK TIE ROD ENDS TEER. RACK TIE ROD ENDS ANTIROLL BAR POWER STEER. PUMP WHEEL ALIGN-BALAN 8. AIRCON AIRCON SERV HEATER HOSE AIRCON CONSUM. AIR CON. PIPE VAPORATOR CONDENSOR EXP. VALVE 9. ELECTRICAL STARTER	BREATHER HOSE TURBO CARBURETTOR INJECTORS INJECTOR WASHER FUEL PUMP FUEL LINE 5. IGNITION SYSTEM HT LEADS IGNITION MODULE DISTRIBUTOR IGNITION SWITCH GLOW PLUGS 6. ENGINE OUTER - OIL LEAKS REAR MAIN SEAL SUMP GASKET/PLUG JUP STICK JUP	BREATHER HOSE TURBO CARBURETTOR INJECTORS INJECTOR WASHER FUEL PUMP FUEL LINE 5. IGNITION SYSTEM HT LEADS IGNITION MODULE DISTRIBUTOR IGNITION MODULE GLOW PLUGS 6. ENGINE OUTER - OIL LEAKS FAN BELT AIRCON BELT AIRCON BELT AIRCON BELT BRAKELIGHT SWITCH OIL SWITCH OIL SWITCH BATTERY BULB BULB INSTRUM. CLUSTER 10. DRIVELINE & SUSP CV JOINT CV JOINT CV JOINT CV JOINT CV JOINT WHEEL BEARINGS BEARING HUBS SHOCKS SHOCK SHOUNTINGS SHOCK SHOUNTINGS SHOCK JOINT	BREATHER HOSE TURBO CARBURETTOR INJECTORS INJECTORS INJECTOR WASHER FUEL PUMP FUEL LINE 5. IGNITION SYSTEM HT LEADS IGNITION ODULE IGNITION WOULE GOLOW PLUGS 6. ENGINE OUTER - OIL LEAKS FEAR MAIN SEAL JDIP STICK JDIP ST

TEST DRIVE	BEFORE	AFTER	FINAL INSPECTION	
PERFORMANCE			ENGINE WASH	
NOISE			VACUUM AND CLEAN	
HANDLING			CLEAN STEERING	
GEARS & CLUTCH			OLD PARTS	
BRAKES			SERVICE STICKER	
VIBRATIONS			SERVICE BOOK	
OVERHEATING		1	WHEELS TORQUED	
WHEEL ALIGNMENT			HUBCAPS	
WHEEL BALANCING			FLUID LEVELS-COOLING	

TECHNICIAN'S SIGNATURE

04-11-2023 DATE